







INSTALL INSTRUCTIONS FOR 75-5080



BEFORE YOU START

This intake kit may not fit with the following Aftermarket • 10mm Wrench & Socket Parts installed:

Body Lift or Lowering Kit

Custom Hood


Throttle Body Spacer / Upgrade

- Please read the entire product guide before proceeding.
- Ensure all parts are present.
- If you are missing any of the components, call our customer support at (909) 947-0015.
- Do not work on your vehicle while the engine is hot.
- Make sure the engine is turned off and the vehicle is in Park or the Parking Brake is set.

REQUIRED TOOLS

- T-20 Security Torx Wrench (Supplied w/ Kit)
- 9/16" Wrench and Socket
- 5/16" Nut Driver or Flat Blade Screwdriver
- Phillips Screwdriver





| ITEM | QTY. | DESCRIPTION | P/N | ITEM | QTY. | DESCRIPTION | P/N |
|------|------|------------------------|------------|------|------|-----------------|------------|
| A | 1 | CLEAR LID | AI1716-00 | О | 1 | GROMMET | AI1563-00 |
| В | 4 | SCREW, TRUSS HEAD | AI1684-00 | P | 1 | GROMMET PLUG | AI1705-00 |
| С | 4 | RUBBER WASHER | AI1571-00 | Q | 1 | BOX PLUG | AI1718C-00 |
| D | 1 | LID SEAL | AI1766-04 | R | 1 | FENDER SEAL | AI1723C-00 |
| Е | 1 | AIR FILTER | KF-1035 | S | 2 | SCREW, M6 | AI1415-00 |
| F | 1 | HOSE CLAMP, #80 | AG1010-00 | Т | 2 | WASHER, M6 | Al1535-00 |
| G | 1 | AIR BOX | AL1241B-00 | U | 1 | HOSE CLAMP, #60 | AG1008-00 |
| Н | 1 | TUBE SEAL | AI1717C-00 | | | | |
| I | 2 | SCREW WITH LOCK WASHER | Al1837-00 | | | | |
| J | 1 | MAF PLATE | AI1722-00 | | | | |
| К | 1 | FOAM GASKET | AI1777-00 | | | | |
| L | 1 | AIR TUBE | AL1241-00 | | | | |
| М | 2 | HOSE CLAMP, #64 | AG1018-00 | | | | |
| N | 1 | COUPLER | AI1337C-00 | | | | |

With the ignition switched off and the parking brake set, disconnect the negative battery cables on both batteries.

IMPORTANT: Failure to disconnect the battery for a minimum of 2 hours may cause the Check Engine Light to illuminate upon completion of the installation or subsequent operation. DO NOT SKIP THIS STEP!



STEP 2

Disconnect the MAF sensor harness



Loosen both hose clamps and remove the stock intake tube from the vehicle.




STEP 4

Pull up on the stock airbox to release the prongs from the two rubber grommets on the stock airbox tray.



STEP 5

Remove the five bolts on the stock airbox tray and remove the tray from the vehicle. Be sure to save the speed clips underneath. They will be reused to install the Airbox (G) in Step 9.



Remove the plastic shield from behind the headlight by prying the tabs loose.



Insert the Fender Seal (R) onto the Airbox (G).



STEP 8

Insert the Tube Seal (H) onto the Airbox (G).

STEP 9

Install the Airbox (G) into the truck. Use the provided Screw and Washer (S & T) to secure the airbox to the truck.



Determine whether or not you want to install the Box Plug (Q).

STEP 11

Remove the sensor from the stock intake tube. Use the provided Foam Gasket (K), MAF Plate (J), and Screws (I) with Lock Washer to install the MAF sensor into the Air Tube (L). The MAF sensor should be installed in the same orientation as shown below.

Note: The MAF connector should be facing the coolant reservoir when installed in the vehicle.



Insert the provided Grommet (P) into the Air Tube (L) if your vehicle came with a Filter Minder.



STEP 13

Insert the filter minder into the grommet.



STEP 14

If you decide you do not want to reuse the filter minder, use the Grommet Plug (P) that was provided instead.



STEP 15

Insert the Air Filter (E) into the Airbox (G)



STEP 16

Slide the Coupler (N) and two #72 Hose Clamp (M) onto the Air Tube (L). Tighten the hose clamp closest to the tube. Leave the other end loose.



Insert the Air Tube (L) first into the Airbox (G) and then slide the other end of the Coupler (N) onto the turbo mouthpiece. Tighten the #72 Hose Clamp (M).



STEP 17 (IMAGE 2)



Slide the Air Filter (E) onto the Air Tube (L) and tighten the #80 Hose Clamp (F).

STOP! READ THIS BEFORE CONTINUING THE INSTALL

If your kit came with our new snap-in lid design, please proceed to **STEP 22** to install your snap-in lid. If your lid is the traditional screw in lid, please proceed to the next step.

STEP 19

Press the Edge Trim Seal (D) into the grooves on the



Remove the protective covering from the Clear Lid (A).

STEP 21

Place the Clear Lid (A) on top of the Airbox (G) and secure the lid using the four provided Screw (B) and Washer (C).



For Snap-In Lids Only

Remove the protective covering from the Clear Lid.

STEP 23

For Snap-In Lids Only

Stretch silicone lid seal around the perimeter of the

clear lid. It should be a snug fit.

STEP 24


For Snap-In Lids Only

The notch on the lid and the tab of the lid seal should mate in the same corner.

Reconnect the MAF sensor harness.

STEP 26

Reconnect the negative terminal on the battery.
Inspect your installation, make sure the kit is properly positioned and all fasteners are secure. The installation is now complete.



WIN A FREE TOOL TRAY

Sign-up below to receive the latest on product launches, insider tips and more. You'll also be entered into a tool tray giveaway where we choose a new winner every week.

Email Address

Sign Up